

Figure 1




Figure 2

300 →




Figure 3A

300 →




Figure 3B




Figure 4 A





Figure 4B

Figure 5






Figure 6

705
Orient the still so the glass top is directed towards the sun.

710
Level the still so that when water is placed in the basin it will be equally distributed across the floor of the basin

715
Install a feedwater supply

725
Attach a collection device to the output of the still

730
Flush the still daily with three or more times the amount of water produced by the still so as to flush out all salts and minerals left behind from the previous days operation.

735
Does the inside of the glass top have residue formed on it?

745
No
Refill still with water daily.

Yes

740
Remove, turn-over, and reseal glass top to basin

Figure 7